



FREQUENTLY ASKED QUESTIONS

Page 19

Questions

1. Do I have to use the track with my Vision 100?
2. Do I need to mount the track to the floor?
3. Can I purchase extra track for extra bays?
4. Where can I store the track when not in use?
5. Do I have to square the track to the vehicle every time I set the unit up?
6. Will I need to compensate for the track when setting floor slope?
7. What kind of warranty does the V100 have?
8. Will I still be covered by the warranty if I do not send in my registration card?

Answers

For best performance, we suggest the track be used to prevent the aimer from moving of 1 parallel when rolling the unit to the left and right side of the vehicle. However, if the shop floor is clean and smooth then the track may not need to be used.

No, the track does not need to be mounted to the floor .

Yes, extra track is available for purchase in 2 sections of 4 feet each.

The track can be stored inside the mast.

The track does not have to be square with the vehicle, only the aimer does. See the Troubleshooting Guide, "Misaligning Lamps."

No, the floor slope scale is designed to compensate for the track thickness.

The Vision 100 is covered by a 90-day replacement warranty and a full year parts and labor .

Yes, but non-registered units will require longer processing time and cause unnecessary confusion. You will also need to include purchase documentation. If a registration card was not received with the V100, call **1-877-343-7703** and one will be sent to you. If registration cards are lost in the mail, we will accept a proof of purchase with a legible date of purchase for warranty coverage.